



# Configuración MQTT

## Comunidad Meshtastic España

Mapa Web: [mapa.meshtastic.es](https://mapa.meshtastic.es)

Datos MQTT:

URL: [mqtt.meshtastic.es](https://mqtt.meshtastic.es)

Usuario: meshdev

Pass: large4cats

A screenshot of the "MQTT Config" interface. It features a dark theme with a list of settings. At the top, "MQTT enabled" is a toggle switch that is turned on (blue). Below it, "Address" is set to "mqtt.meshtastic.es". "Username" is set to "meshdev". "Password" is masked with dots and has an eye icon to toggle visibility. At the bottom, three more toggle switches are shown: "Encryption enabled" (turned on, blue), "JSON output enabled" (turned off, grey), and "TLS enabled" (turned off, grey). These three bottom toggles are enclosed in a red rectangular box.